Lusso IV Chair

User Manual



SKIN+ACT

www.skinact.com | www.spaandequipment.com

Toll Free: 1.800.418.0830

Copyright © 2025 SkinAct, All Rights Reserved

NOTICE

No part of this document may be photocopied, reproduced, or translated into any other language without prior written consent of SkinAct.

The information in this document is subject to change without notice at any time and should not be construed as a commitment by SkinAct. SkinAct assumes no responsibility for any errors that may be in this document, nor does it make expressed or implied warranty with regard to this material, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose.

SkinAct shall not be liable for incidental or consequential damages arising out of the furnishing, performance, or use of this document and the program material which it describes.

SKIN+ACT

www.skinact.com | www.spaandequipment.com

Toll Free: 1.800.418.0830

ASSEMBLY INSTRUCTIONS

Ax1



Cx1




Ex1



Gx1



Bx1



Dx1




Fx1



Hx1




1




Set the seat assembly onto the leg base after inserting the seat piston.

2




The seat and legs ready to continue chair assembly.

3




Lower the armrests into the slots located on both sides of the seat assembly

4



Attach the power cable.

5



Lower the backrest onto the attachment arms until it clicks into place.


ASSEMBLY INSTRUCTIONS

6



Close the back flap and secure the hook and loop strip.


7




Attach the Battery Pack to the power supply, then plug the Battery Pack into the bottom of the chair.

8

Side Controls / USB Connections




9



10

Pull the zipper closed that joins the backrest to the seat cushion



11

Return the chair to the upright position

