SKINACT QUAD 4 IN 1 STEAMER MAG LIGHT HIGH FREQUENCY AND GALVANIC MACHINE

(SKU24092)



SKIN+ACT

TOLL FREE: 1.800.418.0830 | WWW.SKINACT.COM WWW.SPAANDEQUIPMENT.COM | INTERNATIONAL: 818.834.6640

TABLE OF CONTENTS

DISCLAIMER 03

TOOLS 05

PACKING LIST 06

UNIT DIAGRAM 07

ASSEMBLY INSTRUCTIONS 08

ACCESSORY INSTALLATION AND SPRAY ARM ADJUSTMENT 09

CONTROL PANEL 09

HOW TO SET UP STEAMER FUNCTION 10

ATTACHING AND DETACHING THE WATER TANK 11

A GUIDE TO THE CONTROL PANEL 12

GALVANIC FUNCTION AND GALVANIC TREATMENT 13

HIGH-FREQUENCY ELECTROTHERAPY 15

HIGH FREQUENCY TREATMENT 15

IMPORTANT NOTES FOR HIGH-FREQUENCY ELECTROTHERAPY OPERATION 17

LED MAGNIFYING LAMP 17

WARRANTY AND PRODUCT SPECIFICATION DATA SHEET 18

THANK YOU FOR CHOOSING OUR PRODUCT!

Before using the device, we kindly ask you to carefully read the entire instruction manual provided. Please pay close attention to any warnings outlined in this manual. It's important to keep this instruction manual easily accessible at all times. If you pass the device to another individual, please ensure to provide them with the manual, as it is an integral part of the product. Please note that certain components of the product may differ from the images presented in catalogues, websites, brochures, etc. As part of our commitment to continually improve our products, the manufacturer reserves the right to modify features and/or components without prior notice.

THANK YOU AGAIN FOR YOUR PURCHASE. WE HOPE YOU ENJOY USING OUR PRODUCT!

DISCLAIMER

CORRECT USE OF THE DEVICE

• This product is intended for use by beauty professionals in beauty salons and should not be used for other purposes.
• Please be aware that any misuse of the device will result in the loss of warranty coverage.
• Do not attempt to modify the device without authorization.
• We are not liable for any material or personal damage resulting from the misuse of the product.

CONTRAINDICATIONS

• Individuals with pacemakers or heart problems.
• Pregnant women.
• People with sensitive skin, lesions, inflammations, or any skin condition.
• Individuals undergoing medical treatment or diagnostic procedures must obtain medical authorization before using the product.

PRECAUTIONS

• Before using the device for the first time and after each use, inspect the device and mains cable for any damage.
• Always unplug the device from the mains before cleaning or performing maintenance.
• Avoid using the product outdoors or in areas prone to humidity or adverse weather conditions.
• In case of a defective power supply cable, immediately unplug the appliance and notify your dealer or specialized technician.
• Ensure the power supply cable is positioned safely to prevent tripping hazards, and always plug it into a grounded socket.
• At the end of the workday, disconnect the device and unplug the power supply cable from the mains.
• If you notice any abnormalities in the operation of the product, contact your distributor or specialized technician promptly.

HIGHLIGHTS

This revolutionary equipment features a steamer, magnifying light, high frequency and galvanic capabilities all in one convenient device. With its versatile design, this powerful piece of equipment offers multiple services in one machine. For professional aestheticians or beauty centers looking for an efficient and cost effective device that offers multiple services, the Quad 4 in 1 is the ideal choice as it does it all! Experience convenience on a whole new level with revolutionary Quad 4 in 1!

FEATURES:

- Facial Ozone Steamer: Steam intensity, timer and ozone option.
- Magnifying LED Light: Adjustable arm, bright cool-tone LED, and magnifying lens.
- High Frequency: 5 professional glass electrods, high frequency handle, intensity level adjustment.
- Galvanic: Negative and positive ion currents, intensity adjustment level, 1 galvanic roller and 1 galvanic rod.

SPECIFICATIONS:

- Glass beaker: 35 oz
- 1-year limited warranty

SAFETY

- Please keep the device and its accessories out of the reach of children.
- Only plug the device into a properly installed socket. The local mains voltage must correspond to the technical specifications of the device.
- The power socket must be accessible in case you have to quickly unplug the device at any given time.
- Always pull out the plug from the socket and not the mains cable.
- Never tamper with any electrical component or open up/repair any component of the device. Only your distributor or specialized technician should repair the device. Do not switch on the device if there is any visible damage to it or to the mains cable.
- Never touch the device or the mains cable with wet hands.

WARNINGS

WHEN USING THE HOT SPRAYING FUNCTION

- It is forbidden to put oily materials into the water cup or herbal net as it may cause water spraying problems.
- Do not spray steam directly above the face from the steam hole to avoid scalding.
- Avoid placing the machine in environments with excessive humidity, such as bathrooms.
- Avoid operating the machine in direct sunlight as it may lead to unstable conditions.
- If there are any issues, please contact the agency for professional maintenance instead of attempting to repair the machine yourself.
- If the power cord is damaged, it is recommended to obtain accessories from the original factory. Do not attempt repairs yourself; instead, visit an authorized repair agency.

WHEN USING THE HIGH-FREQUENCY ELECTROTHERAPY FUNCTION

- Avoid contact with any metallic objects during high-frequency electrotherapy, and remove any metallic accessories.
- Individuals with sensitive skin, patchy skin, acne rosacea, open wounds, pregnant women, or those with other medical instruments (e.g., cardiac pacing devices) should not use this function.
- Do not use creams or face masks containing ethanol during high-frequency electrotherapy. If ethanol-containing toner must be used, apply it after the therapy.
- Avoid directing electrotherapy tubes towards the eyes.
- Do not touch the main input port or handle input port of the high-frequency electrotherapy device while it is live.
- Ensure that the plug of accessory flexible cables is securely fixed to the corresponding outputs of the machine.
- This instrument should be operated by professional beauticians to avoid interference with other electronic devices and to exercise caution during use.

WHEN USING THE GALVANIC CONDUCTION FUNCTION

- Patients with heart disease, infectious diseases, neurological conditions, or metallic implants should not use this function.
- Avoid prolonged contact between the working conduction and export probes.
- Replenish skin care essence promptly when it is insufficient for moisturizing.
- Replace non-rotating sliding rollers promptly.
- Prevent water or corrosive liquids from coming into contact with the machine during use.
- Avoid using round probes and roller probes with damaged, rusty, or worn surfaces to prevent skin injury. Take care to protect the probes from damage by hard objects.

TOOLS



FACIAL OZONE STEAMER WITH GOOSE HANDLE: Moisturizes, cleanses, and opens pores. Adjustable extension arm for wider steam coverage. Includes timer and alarm settings. Enjoy enhanced hydration, circulation, and cell oxygenation. Use with essential oils for a customized spa experience.



MAGNIFYING LED LIGHT: Magnifying lamp consists of optical lens and soft light of cold lamp tube. It can make observation cleaner, so acne and dark spots are more easily to be found. It is very suitable treatments and skin analysis.











HIGH FREQUENCY: This advanced technology uses powerful electrical current to encourage oxygen circulation in the skin, pushing out toxins and promoting a healthier complexion. Its anti-aging properties stimulate collagen and elastin production, providing a more firm and youthful appearance.




GALVANIC: Galvanic technology is the latest advance in skin care treatments. It uses direct electrical current to deliver hydration and nutrients directly to your skin by using negative and positive ion currents. By promoting absorption into the surface layer, you will experience maximum results.

PACKING LIST


Item	Product Description	QTY
The 4-in-1 Facial Care Machine		1 SET
Column		1 pcs
Five Leg Standing		5 pcs
Five Leg Base		1 pcs
Five Leg Plat Broad		1 pcs
M10 Screws		1 SET
M6 Screw		5 pcs
Wrench		1 pcs
Magnifying lamp		1 pcs
Gavanic probe		1 SET
High-frequency Electrotherapy Handle		1 pcs
Mushroom-shape Glass Electrotherapy Tube		1 pcs
Spoon-shape Glass Electrotherapy tube		1 pcs
Dot Glass Electrotherapy Tube		1 pcs
Straight-Bar Glass Electrotherapy Tube		1 pcs
Accessory rack		1 pcs
Instruction Manual		1 copy

UNIT DIAGRAM




1. water-in cover and aroma basket
2. water filling port
3. control panel
4. Handle
5. Heating element
6. Water cup
7. Power plug
8. Water container holder
9. Low Water Probe
10. High Water Probe
11. Pole support
12. Power Switch
13. High frequency Output Port
14. Gavanic Port
15. Steamer arm latch

Steamer Base Components



1. Five-Leg Base
2. Column
3. fixing sleeve
4. Five Leg Base
5. Five Leg Plat Broad
6. M6 Screw
7. M10 Screws


Steamer Arm Components



1. Spray Arm
2. Essential Oil Cotton Holder
3. Essential Oil Sliding Cover
4. Steam Outlet


ASSEMBLY INSTRUCTIONS

1. Attach the five leg to the five-star base first and ensure it is pressed firmly.
2. Cover with the plate and secure it along with the five leg using five M6 screws.
3. Place the fastening sleeve on one end of the column and insert it into the five-star base.
4. Use M10 screws, washers, and spring washer to firmly secure the column in the five-star base.
5. Ensure the column is not loose.
6. Attach the magnifying lamp mount securely and tighten it. Place the host and the magnifying lamp on the base and the mount to complete the assembly.




ACCESSORY INSTALLATION AND SPRAY ARM ADJUSTMENT

1. Glass Electrotherapy Tube Holder
2. High frequency probe Holder
3. Galvanic probe Holder
4. Galvanic Rod Holder




1. Secure the additional frame to the body using the included screws, following the direction of the arrow.
2. Position the accessories as shown and insert the plug into the corresponding socket according to the labeled instructions.



UNLOCKING THE SPRAY ARM

Before packing and removing the machine, the spray arm may be locked in a fixed position. To unlock it, rotate the spray arm to a horizontal position, as shown in the following image.


CONTROL PANEL



1. Level Window
2. Level Adjustment
3. Ion Conduction Selection
4. Function Selection
5. Start/Pause Button
6. Ozone On and Off Power Buttom
7. Steamer Power
8. Time Decreasing Button
9. Time Increasing Button
10. Steamer Control
11. Steamer Volume Selection
12. Steamer Volume Indicator
13. Water in cover and aroma basket

HOW TO SET UP STEAMER FUNCTION

The spray arm features a special design, allowing adjustment to different angles to suit various environments. Please refer to the following pictures:




• The spray arm can be adjusted to a 50-degree angle in the left-right direction and a 20-degree angle in the up-down direction. Additionally, the spray head can be rotated 360 degrees, while the spray arm can adjust it around to 130 degrees. (Refer to Figures 1, 2, 3)

IMPORTANT NOTES

Adjust the spray arm only within the designated limits. Using excessive force to adjust it beyond these limits may cause water leaks/ splashing hot water or component damage. Such damage will not be covered under warranty.


WATER AND BOTANICAL PREPARATION:

Open the lid and pour water into the reservoir. The water level should be between the minimum and maximum fill lines on the water level indicator (as shown in the picture).




FOR A SOOTHING STEAM TREATMENT:

1. If you'd like to add botanicals for a more fragrant steam, remove the botanical basket from the water inlet lid.
2. Place your desired dried herbs or botanicals into the basket.
3. Return the basket to the water inlet lid and securely screw the lid back on.



FOR ESSENTIAL OIL AROMATHERAPY:

1. Use the dropper to add one or two drops of essential oil onto the cotton pad (as shown in the right picture).
2. If you wish to switch to a different essential oil for your aromatherapy session, remove the essential oil cover from the spray nozzle.
3. Use tweezers to remove the used cotton pad and replace it with a new one. Add your desired essential oil and secure the essential oil cover back on.



ATTACHING AND DETACHING THE WATER TANK

BEFORE DETACHING THE WATER TANK:


1. Ensure the power to the unit is turned off.
2. Wait for the water tank to cool completely.

DETACHING THE WATER TANK:


1. Hold the water tank with one hand.
2. With the other hand, grip the indentation at the bottom of the water tank.
3. Turn the indentation clockwise and follow the arrow until it clicks, detaching the tank.

ATTACHING THE WATER TANK:

1. Ensure the power to the unit is turned off.
2. Hold the water tank with one hand.
3. Align the water tank opening with the base of the unit.
4. To secure the attachment, locate the indentation and rotate it clockwise until it clicks and locks into place.





A GUIDE TO THE CONTROL PANEL



1. **Power On:** Plug in the power cord and turn on the power switch.
2. **Standby Mode:** When the power is turned on, the indicator light will illuminate. The timer will display "15 minutes" and the energy level indicator will show the highest setting. The ozone function light and the steam function light will be off.
3. **Steam Function:** Turn on the "Warm/Vapor" switch. The steam function light will turn on. The steamer will begin heating, and steam will come out of the nozzle in approximately six minutes.
   Warm Function: You can also turn on the "Warm/Vapor" switch only to activate the warming function. The warm function light will illuminate and the steamer will begin heating. (No steam will be produced in this mode.)
4. **Time Setting:**
   Steam Mode: Use the "+" and "-" buttons next to the "Timer" label to adjust the desired working time. The time range for steam mode is 1 to 30 minutes, with a default setting of 15 minutes.
   Warm Mode: When using the warm function only, the time range is 1 to 90 minutes, with a default setting of 30 minutes.
5. **Energy Setting:** Press the "Steamer Handle" button to adjust the steam output level. You can choose from high, medium, or low mist. The indicator lights on the display will show the selected level (full bars for highest, fewer bars for lower). It's recommended to start with the highest setting before adjusting as needed.
6. **Ozone Function:** Press the ozone switch. The ozone indicator light will turn on, indicating that the ozone function is activated. You may smell ozone in the steam, along with a noticeable atomization effect.
7. **Water Level Detection:** The steamer automatically detects the water level during heating ("Warm/Vapor" mode).
   Normal Operation: If the water level is within the normal range (between the maximum and minimum markings), the steamer will continue heating.
   Low Water Level: If the water level is too low, the timer display will show "E1" and the steamer will stop heating immediately. The "Warm/Vapor" light will turn off and the buzzer will sound an alarm ("De De") continuously until the water level is refilled. All buttons will be locked until the water level is restored. Press the "Warm/Vapor" button again to resume operation after refilling.
   High Water Level: If the water level is too high, the timer display will show "E2" and the steamer will stop heating immediately. The "Warm/Vapor" light will turn off and the buzzer will sound an alarm ("De De") continuously. All buttons will be locked until the water level is reduced to a safe level. Press the "Warm/Vapor" button again to resume operation after correcting the water level.


IMPORTANT NOTES:





- Always ensure the water tank is properly secured and filled to the correct level before powering on the machine and throughout operation.
- When using essential oils, turn off the steamer first. Add them only to designated areas. **Never add essential oils to the water tank**
- Clean the cotton pad in the essential oil base after each use.
- **For best results, wait a moment for the mist to settle before spraying your face**
- **Maintain a safe distance of at least 16 inches from the customer's face to avoid scalding.**
- Prolonged exposure to ozone or direct skin contact can cause irritation, including dryness, redness, and burning.
- Avoid overexertion when adjusting the spray arm.
- Allow the water tank to cool before disassembly to prevent scalding.
- Overfilling the water tank can lead to leaks and potential electrical issues. Please fill only to the indicated level. Replace the water daily and clean the water cup thoroughly after each use.
- Regularly clean the machine to prevent buildup.

GALVANIC FUNCTION



ACCESORIES

1. Conduction Probe
2. Plug for Conduction Probe Flexible Cable
3. Conduction Probe Flexible Cable
4. Roller (Face) Probe
5. Round (Eye) Probe
6. Sphere (Face) Probe

INSTRUCTIONS:

1. **Attaching a Probe:** Select a suitable probe for your desired treatment area (face or body) and attach it firmly to the handle.
   - **Roller Probe:** Suitable for both face and body use (6).
   - **Sphere Probe:** Recommended for facial use (5).
   - **Round Probe:** Recommended for facial use (4).
2. **Selecting Galvanic Function:**
   - Ensure the machine is in standby mode.
   - Press the "SELECT FUNCTION" button to choose the Galvanic function. The indicator light will illuminate, indicating the machine is ready for adjustment.
3. **Ion Conduction Polarity Selection (Applicable Probes Only):**
   - **Note:** This step applies only to probes with a red flexible cable.
   - Press the "+" or "-" button to select the desired output polarity.
   - **(+) indicator:** Indicates cation conduction mode.
   - **(-) indicator:** Indicates anion conduction mode.
4. **Starting or Pausing Output:**
   - When the machine is in standby mode or after completing adjustments, press the "Start/Pause" button to begin or pause the output.
   - A lit indicator light signals the machine is actively delivering current.

GALVANIC TREATMENT

IMPORTANT SAFETY INFORMATION

Read all instructions carefully before using the device.
Consult with your doctor before using this device if you have any of the following conditions:

- Pacemaker or other implanted medical devices
- Epilepsy
- Pregnancy
- Open wounds or irritated skin
- Active cancer
- Metal implants in the face

COMPONENTS:

- Galvanic Beauty Machine
- Metal Rod Handle
- Positive Handle with Detachable Tips (Sphere, Round, Roller)

STEP 1: PREPARATION

1. **Cleanse and Dry Skin:** Thoroughly cleanse your face with a gentle cleanser and pat it dry with a clean towel.
2. **Choose Your Handle and Tip:** The machine offers two handles for targeted treatments:
   - **Metal Rod Handle:** Primarily used for a specific treatment.
   - **Positive Handle:** This handle accepts various attachments for another treatment.
     - **Sphere Tip:** Suitable for targeted application.
     - **Round Tip:** Ideal for broader application.
     - **Roller Tip:** Offers a massaging effect while applying product.
3. **Prepare Your Skincare Product:** Select a water-based skincare product compatible with galvanic treatments. Gels or serums work well. Apply a thin layer to the targeted area(s) on your face.

STEP 2: MACHINE SETUP

1. **Attach Chosen Handle:** Choose the appropriate handle based on your desired treatment.
2. **Polarity Switch:** Locate the polarity switch on the machine.
3. **Intensity Setting (Optional):** Start with the lowest setting and gradually increase to a comfortable level.

STEP 3: TREATMENT

1. **Treatment Technique:**
   Follow the specific instructions for proper technique with the selected handle. Use smooth, gliding motions on the treatment area.
2. **Treatment Time:** Generally, facial treatments can last 5-10 minutes per area. Avoid prolonged treatment on any specific location.

STEP 4: POST-TREATMENT CARE

1. **Turn Off Machine:** Turn off the machine and unplug it from the power outlet.
2. **Remove Product Residue:** Gently remove any remaining skincare product with a damp washcloth.
3. **Moisturize:** Apply a hydrating moisturizer to soothe the skin and replenish moisture.

STEP 5: CLEANING AND STORAGE

1. **Detach and Clean Tips (if used):** Unscrew and detach any used attachments (sphere, round, or roller) from the positive handle. Wipe all tips and the metal rod with a damp cloth dipped in an alcohol solution to disinfect. Allow them to air dry completely before storing.
2. **Clean Handles:** Wipe both handles with a damp cloth for hygiene.
3. **Store Machine:** Store the machine and detached accessories in a cool, dry place.


DISCLAIMER

The information provided in this user manual is intended for general guidance only. It is not a substitute for professional medical advice. Always consult with your doctor before using this device, especially if you have any underlying health conditions.


HIGH-FREQUENCY ELECTROTHERAPY

ACCESORIES

1. Electrotherapy Tube
2. High-Frequency Electrotherapy Handle
3. Plug for Electrotherapy Handle Flexible Cable
4. Electrotherapy Handle Flexible Cable




SELECTING THE RIGHT GLASS ELECTROTHERAPY TUBE FOR TREATMENT



1. **Mushroom-shaped Glass Electrotherapy Tube:** This tube is suitable for treating large areas such as the cheeks, forehead, and neck.
2. **Spoon-shaped Glass Electrotherapy Tube:** Ideal for medium-sized areas such as the chin.
3. **Dot Glass Electrotherapy Tube:** Designed for treating small areas like the nasal pit.
4. **Straight-Bar Glass Electrotherapy Tube:** Used for indirect treatment.

ELECTROTHERAPY TUBE ASSEMBLY AND DISASSEMBLY



1. Glass Part of Electrotherapy Tube
2. Metal Electrode of Electrotherapy Tube

HIGH FREQUENCY TREATMENT

IMPORTANT SAFETY INFORMATION

Read all instructions carefully before using the device.
Consult with your doctor before using this device if you have any of the following conditions:

- Pacemaker or other implanted medical devices
- Epilepsy
- Pregnancy
- Open wounds or irritated skin
- Active cancer
- Metal implants in the face
- Never touch the glass electrode while the device is turned on.
- Do not use the device near flammable materials.

COMPONENTS:

High-frequency machine
Glass applicator tubes (mushroom, spoon, dot/spot, rod)

STEP 1: PREPARATION

1. **Cleanse and Dry Skin:** Thoroughly cleanse your face with a gentle cleanser and pat it dry with a clean towel.
2. **Choose the Applicator Tube:** Select the appropriate glass applicator tube for your desired treatment:
   Mushroom: General facial stimulation and blood circulation.
   Spoon: Puffiness under the eyes and lymphatic drainage.
   Dot/Spot: Targeted spot treatment for blemishes (use with caution).
   Rod: Indirect treatment over a broad area (use with a gauze pad).
3. **Apply Conductive Medium (Optional):** For smoother gliding and improved results, consider a thin layer of conductive gel or lotion on the treatment area.

STEP 2: MACHINE SETUP

1. **Insert Applicator Tube:** Gently insert the chosen glass applicator tube into the handpiece slot of the high-frequency machine. Push the metal area in firmly until it feels secure.
2. **Power On:** Turn on the machine.
3. **Adjust Intensity (Optional):** Start with the lowest setting and gradually increase to a comfortable level.

STEP 3: TREATMENT

1. **Treatment Technique:**
   For Mushroom, Spoon, and Dot/Spot tubes: Glide the chosen applicator tube across the treatment area in smooth, circular motions. Maintain a slight distance (around 1/4 inch) between the glass tube and your skin to avoid sparking.
   For Rod Tube: Wrap a thin gauze pad around the glass rod applicator. Glide the gauze-covered rod tube over the treatment area in smooth, circular motions. Maintain a slightly larger distance (around 1/2 inch) due to the indirect treatment nature.
2. **Treatment Time:** Generally, facial treatments last 5-10 minutes. Avoid prolonged treatment on any specific area.

STEP 4: POST-TREATMENT CARE

1. **Turn Off Machine:** Turn off the machine and unplug it from the power outlet.
2. **Remove Conductive Medium (if used):** Gently remove any remaining conductive gel or lotion with a damp washcloth.
3. **Moisturize:** Apply a hydrating moisturizer to soothe the skin and replenish moisture.

STEP 5: CLEANING AND STORAGE

1. **Remove Applicator Tube:** After treatment, remove the glass applicator tube by gently pulling it out of the handpiece slot.
2. **Clean Applicator Tube:** Wipe the glass applicator tube with a damp cloth dipped in an alcohol solution to disinfect it. Allow it to air dry completely before storing.
3. **Store Machine:** Store the machine and applicator tubes in a cool, dry place.

DISCLAIMER

The information provided in this user manual is intended for general guidance only. It is not a substitute for professional medical advice. Always consult with your doctor before using this device, especially if you have any underlying health conditions.

IMPORTANT NOTES FOR HIGH-FREQUENCY ELECTROTHERAPY OPERATION

- **Normal Sounds:** Squeaking sounds during normal operation of the electrotherapy handle are expected.
- **Spark Prevention During Direct Treatment:**
  Sparks may occur if the glass tube is held less than 1 inch from the skin, causing discomfort.
  To prevent this:
  • Adjust the energy level to the minimum setting before making contact with the skin.
  • If sparks are still felt, cover the face with a thin layer of dry cotton mask.
- **Proper Contact:** Ensure the electrode tube is firmly sealed against the face without any gaps to prevent sparks and potential skin irritation.
- **Treatment Time:**
  -The recommended treatment duration is:
  • 8 minutes for oily skin
  • 3-5 minutes for dry skin
  -The current intensity is typically stronger for oily skin treatments.
- **Indirect Treatment:** During indirect electrotherapy, the operator should keep one hand on the client's face to maintain a continuous current and prevent a loss of treatment effectiveness.
- **Safety Precautions:**
  • To prevent electric shock, always press the "START/PAUSE" button before the glass tube touches the skin. Then, slowly increase the energy level.
  • When removing the glass tube, first adjust the energy level to the minimum setting and press "START/PAUSE" to shut down the output completely.
- **Power Management:**
  • Always turn off the machine's power before installing or uninstalling the glass electrotherapy tube.
- **Cleaning and Maintenance:**
  • Keep each glass electrotherapy tube clean, dry, and sterilized before and after each use.
  • Clean the electrotherapy handle with a damp towel. Do not immerse it in water.
  • If the handle is contaminated with oily dirt, clean it with a solution of absolute alcohol and water. Allow it to dry completely before storing in a clean, dry place.

LED MAGNIFYING LAMP SETUP

1. **Placement:** Place the magnifying lamp into the designated slot on the host machine.
2. **Connection:** Connect the lamp's plug to the corresponding socket on the machine.
3. **Positioning:** Open the anti-dust cover and adjust the lamp to the desired position using the adjustment joint.
4. **Power On**: Turn on the power switch to begin the beauty treatment.

SAFETY PRECAUTIONS

- **Pinch Hazard:** When adjusting or moving the magnifying lamp, avoid placing your fingers between the upper and lower arms to prevent them from getting pinched.
- **Skin Preparation:** Cleanse your skin thoroughly before using the magnifying lamp.
- **Power Down:** Always turn off the power switch after completing your treatment.
- **Storage:** If you won't be using the machine for an extended period, unplug it from the power source. Ensure the machine is clean and store it in a suitable location.

SpaandEquipment offers a 1-year limited warranty on most equipment, covering malfunctions and manufacturer defects only (parts only, shipping not included). Warranty is void for improper use, wear & tear, alterations, or lack of professional installation for plumbing & electrical equipment (proof required). Customers are responsible for return shipping costs and damage during return shipment voids warranty (ship with insurance).

For details or questions, contact SpaandEquipment.com at 1.800.418.0830.

For further details regarding warranty coverage, please refer to our Warranty Information Policy on our website.
You can find it under the "Return/Shipping/Warranty" section.

SPECIFICATIONS AND TECHNICAL DATA

PRODUCT NAME:
SkinAct Quad 4 In 1 Steamer Mag Light High Frequency And Galvanic Machine (SKU24092)

FUNCTION:
Ion Facial Steamer, Magnifying Lamp, Galvanic, High-Frequency

SPECIFICATIONS:
Rated Voltage/Power: AC 100-130V / 750W
Working Frequency: 50/60Hz
Dimensions: 3.40" x 1.34" x 1.14" (H x W x D)
Weight: 32.85 lbs